CABINET KNOB · GTV PIAZZA COLLECTION

PIAZZA Cabinet Knob, *brass*

A 30 mm square knob with softened corners and a waisted stem, made in zinc alloy. A neat, modern finish for doors and drawers.

SCREW INCLUDED

FIXING	LENGTH
1 × M4 screw	30 mm
WIDTH	**PROJECTION**
30 mm	27 mm
MATERIAL	**DRILL**
Zinc alloy	Ø5 mm

Specification

Product code	GZ-PIAZZA-1-03
Collection	GTV PIAZZA
Type	Square knob with waisted stem
Length	30 mm
Width	30 mm
Projection from front	27 mm
Fixing	Single central M4 screw
Material	Zinc alloy (ZnAl, zamak)
Colour	Brass
Surface	Plated
Screws included	Yes
Drill size	Ø5 mm through the front
Style	Modern
Packaging	Individually packed

Ideal for

Kitchen doors · Drawer fronts · Bedroom furniture · Dressers & chests · Bathroom vanities · Utility rooms

Size & fixing point

Front view of the knob on the door



One fixing at the centre of the knob. Drill Ø5 mm straight through the front.
Square knob — line the edges up square to the door before the final turn.

Side profile & screw length

Section through the door



Projection 27 mm from the face of the front.
Screw length ≈ front thickness + 4–5 mm (18 mm front → M4 × 22 mm).

Fitting in six steps

01 Choose the position
Doors: usually 50–80 mm in from the opening edge and corner. Drawers: centred. Keep every knob in the room at the same position.

02 Mark the centre
Mark the fixing point with a pencil cross. A simple card or drilling jig keeps every door the same.

03 Drill the hole
Drill Ø5 mm straight through, square to the face. Clamp a scrap block behind to stop the back breaking out.

04 Check the screw
The screw should be front thickness + 4–5 mm. For thick or panelled fronts use a longer M4 screw.

05 Fix the knob
Push the screw through from the back and thread it into the knob. Tighten by hand.

06 Align and finish
Turn the knob to its final position, then nip the screw up. Do not overtighten — the thread is in the knob.

Good to know

- Test the position on one door first, then make a template for the rest.
- On high-gloss or painted fronts, put masking tape over the mark before drilling.
- Use a sharp wood or brad-point bit for a clean hole.
- Clean with a soft, damp cloth and dry. No abrasive pads or solvents.
- Avoid bleach and limescale removers near plated finishes.
- For indoor furniture. Keep away from direct heat sources.

The PIAZZA collection at ABJ

Same design and finish quality across the range. Choose a size and colour to match the rest of your room.

Knob · Brushed steel | **Knob · Brass** | Knob · Brushed gold | Knob · Matt black

SCAN TO ORDER

Technical data from the manufacturer's published product card for the GTV PIAZZA collection. Dimensions in millimetres and may vary by ±1 mm. Always check hole positions on a scrap piece before drilling. GTV is a trademark of GTV Poland S.A.; ABJ Accessories is an independent UK stockist. Questions about fitting or bulk orders: info@abjaccessories.co.uk.